AbsolutAire, Inc. - LTL Freight Rate Chart

- Use for Standard configurations of V1 thru V5 models & AA1700 thru AA4 models (consult factory for others)
- PLEASE NOTE: if a roof curb, angle stand, etc. needs to ship separate / advance, consult factory for add'l. freight costs.

